
Nº	CODE	DESCRIPTION
1	BP815S01	AIR MOTOR ASSY
2	BP815S02	END CAP SWITCH ASSY
3	BP815S03	EN CAP SCREWS
4	BP815S04	HAMMER CASE ASSY
5	BP815S05	ANVIL ASSY
6	BP815S06	HAMMER DOGS-PIN SET
7	BP815S07	HAMMER FRAME
8	BP815S08	HOUSING ASSY
9	BP815S09	MAINTENANCE KIT

MAINTENANCE KIT:

- 6 rotor blades
- 1 Rear gasket
- 1 front gasket
- 1 anvil O-ring
- 1 anvil clip
- 1 air valve spacer-gasket




BP815S




















Not numbered parts are shown drawing for illustration purposes. Available parts are supplied by kits but not individually.

SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

Revision: 00

10052025