


Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
1	BP90101	CHECK RING	27	BP90127	VALVE STEM
2	BP90102	SCREW	28	BP90128	STEM COVER
3	BP90103	HAMMER CASE	30	BP90130	TRIGGER
4	BP90104	HANDLE	31	BP90131	SPRING PIN
5	BP90105	SPRING WASHER	32	BP90132	SPRING PIN
6	BP90106	SCREW	33	BP90133	SCREW
7	BP90107	BUSHING	34	BP90134	SPRING WASHER
8	BP90108	O-RING	35	BP90135	WASHER
9	BP90109	RETAINER RING	36	BP90136	GASKET
10	BP901L01	ANVIL 9"	37	BP90137	BEARING
11	BP90111	HAMMER	38	BP90138	REAR END PLATE
12	BP90112	COVER	39	BP90139	SPRING PIN
13	BP90113	HAMMER CAM	40	BP90140	ROTOR BLADE (1 UNIT)
14	BP90114	HAMMER CAGE	41	BP90141	ROTOR
15	BP90115	ADAPTOR, HOSE	42	BP90142	SPRING PIN
16	BP90116	O-RING	43	BP90143	CYLINDER
17	BP90117	STEEL BALL	44	BP90144	FRONT END PLATE
18	BP90118	SPRING	45	BP90145	BEARING
19	BP90119	REGULATOR	46	BP90146	HOUSING
20	BP90120	SPRING PIN	47	BP90147	WASHER
21	BP90121	O-RING	48	BP90148	GASKET
22	BP90122	SPRING PIN	49	BP90149	OIL SEAL
23+29	BP90129	HOUSING+BUSHING	50	BP90150	SCREW
24	BP90124	SPRING	51	BP90151	SCREW
25	BP90125	STEEL BALL	52	BP90152	O-RING
26	BP90126	WASHER	53	BP90153	BAND



BP901L



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe