


Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
1	BP905P01	MOTOR HOUSING	24	BPC81419	STEEL BALL 9/64"
2	BP905P02	SPRING PIN	25	BP905L23	ANVIL BUSHING
3	BP905P03	AIR INLET	27	P82102	SPRING PIN
4	BP905P04	TRIGGER	28	BP905L26	HAMMER CASE
5	P82208	O-RING	29	BP905L27	GASKET
6	BP905P05	BUSHING	30	BP905L28	SCREW M6X25 (8)
7	BP905P06	EXHAUST DIFFUSER	32	BP905L30	WASHER
8	BP905P07	O-RING	33	BP905L31	HAMMER CAGE
9	BP905P08	O-RING	34	BP905L32	HAMMER (2)
10	BP905P09	REVERSE VALVE	35	BP905L33	HAMMER PIN (2)
11	BP905P10	GASKET	36	BP905P14	ANVIL 1"
12	BP905P11	REAR COVER	37	BP905L35	O-RING
13	BP905L12	BALL BEARING	38	BP905L36	RETAINING RING
14	BP905L13	REAR END PLATE	39	BPC81413	SPRING PIN
15	BP905L14 BP905L14B	ROTOR	40	BP905L38	HANDLE
16	BP905L15 BP905L15B	ROTOR BLADE (6)	41	BP905L39	SCREW M6X20 (4)
17	BP905L16	SPRING PIN (3)	42	BP905P15	VALVE SPRING
18	BP905L17	CYLINDER	43	BPC81732	VALVE STEM
19	BP905L18	FRONT END PLATE	44	BP905P16	RUBBER SPACER
20	BP905L19	BALL BEARING	45	BP905P17	O-RING
21	BP905P12	REVERSE LEVER	46	BP905P18	VALVE BUSHING
22	BP905P13	O-RING	47	BP905P19	DAMPING DIFFUSER
23	BPC81418	SPRING	51	BP905L46	HEX. WRENCH 5MM





***IMPORTANT: for blades and rotors purchase orders, check first the thickness of the used blades and rotors:**

3.9mm blade: BP905L15
4.9mm blade: BP905l15B
4mm rotor: BP905L14
5mm rotor: BP905L14B



BAHCO

BP905P

SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

Revision: 00

30062022