


Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
2	P82302	SPRING PIN (3X24L)	37	P82334	DISC COVER
3	P82303	AIR INLET	38	P82335	FLANGE (M14X2)
4	BP82304	THROTTLE LEVER	39	P82336	SPRING PIN
5	P82305	PIN	40	BP82337	FLANGE NUT (M14X2)
6	P82306	VALVE SEAT	41	P82338	ADJUST SCREW
7	P82307	O-RING	42	P82339	ADJUST NUT
8	P82308	SPRING	43	P82340	CAP SCREW (M5X16)
10	P82309	VALVE STEM	44	P82341	INLET GUIDE
12	P82310	PLUNGER	45	P82342	SPRING
13	P82114	BALL BEARING (608ZZ)	46	P82343	GOVERNOR
14	P82311	REAR PLATE	47	P82344	PENDULUM
15	P82312	ROTOR	48	P82345	SPRING PIN (3X12L)
16	P82313	ROTOR BLADE (1 UNIT)	49	P82346	O-RING
17	P82314	SPRING PIN	50	P82227	SPRING
18	P82315	CYLINDER	51	P82347	SAFETY BAR
19	P82316	FRONT END PLATE	52	P82348	SPRING PIN(2X18L)
20	P82317	BALL BEARING (6201Z)	53	BP82349	EXHAUST DIFFUSER
21	P82318	GASKET	54	P82350	VIBRATION REDUCED
22	P82319	BEVEL GEAR	55	P82351	PIN WRENCH
23	BP82320	GEAR HOUSING	56	P82356	RETAINING RING
24	P82321	SPRING WASHER	57	P82357	BUSHING
25	P82322	SCREW	58	P82208	O-RING (10.5X1)
26	P82323	SPACER	59	P82359	SPRING PIN
27	P82324	SCREW	60	P82360	PINDLE STOP BUTTON
28	P82325	BALL BEARING(626ZZ)	61	P82361	SET SCREW (M5X8)
29	P82326	RETAINING RING	62	P82362	O-RING(27X2)
30	P82327	REP N 30 BEVEL GEAR	63	P82363	CLAMP
31	P82328	WAVE WASHER	64	P82364	HOSE
32	P82329	BALL BEARING	65	P82365	EXHAUST HOSE
33	P82330	SPINDLE	66	P82366	O-RING
34	P82331	KEY	79	P82368	FELT OILER
35	P82332	GASKET	80	P82369	STEADY
36	P82333	RETAINER			



BP823

Revision: 01



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

12022026