Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
1	BP82701	MOTOR HOUSING	29	P82618	DRIVE DOG
2	P82602	PIN(2.5*26.8)	30	P16027	RETAINING RING
3	P82603	AIR INLET	31	P82039	STEEL BALL (1/8")
4	BP82604	TRIGGER	32	BP82619	EXH. DIFFUSER
5	P82605	VALVE STEM	33	P82620	EXH. DIFFUSER
6	P82606	VALVE BUSHING	34	P82621	DAMPING METAL
7	P82607	ORING 4.5*2.5	35	P82622	SPRING
8	P82608	ORING 15.5*1.5	36	P82623	SNAP-RING
9	P82609	ORING 12.1*1.6	37	P82624	CAM SPINDLE
10	P82610	REVERSE LEVER	38	P82625	CLUTCH
11	P16010	MOTOR GASKET	39	P82627	THRUST WASHER
12	P16012	END PLATE	48	P82704	SPRING
13	P83235	FLANGE (M14X2)	49	P82629	WASHER
14	P82611	REAR END PLATE	50	P82630	ADJUST NUT
15	P82612	ROTOR	51	P82631	SPACER
16	P16014	ROTOR BLADE (1	52	P16034	BALL RETAINER
17	P82613	PIN 2.5*57	53	P16035	SPRING
18	P82616	WORK SPINDLE	54	P16036	WASHER
19	P16017	FRONT END PLATE	55	P82632	CLUTCH HOUSING
22	P16020	INTERNAL GEAR	56	P16018	SPRING
23	P82701	PLANET GEAR	57	P16019	SPRING GUIDE
24	P82118	SET OF 3 PINS	58	P16050	CENTER GEAR
25	P82702	NEEDLE BEARING	59	P16037	PINION GEAR
26	P82703	NEEDLE BEARING	60	P82633	KEY
27	P16024	BALL BEARING	61	P82634	HEX WRENCH
28	P16025	CLAMP NUT	64	P82635	DECORATING RING

BAHCO


BP827

Revision: 01

(UNITS PRODUCED BEFORE 2020)



- For units produced before 2020, refer to **BP827 V1** exploded view



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

12022026